


BWM LSD30

Spare Parts Diagram

Section A. Main Body




Ref #	Part No.	Description	Qty
1	BWMLSD300001	Beam Weldment	1
2	BWMLSD300002	Screw M12x55	12
3	BWMLSD300003	Flat Washer Ø12	24
4	BWMLSD300004	Lock Washer Ø12	12
5	BWMLSD300005	Thick Nut M12	12
6	BWMLSD300006	Keeper Spacer	2
7	BWMLSD300007	Keeper Plate	2
8	BWMLSD300008	Lock Washer Ø18	4
9	BWMLSD300009	Flat Washer Ø18	4
10	BWMLSD300010	Hex Nut M18	4
11	BWMLSD300011	Beam	1
12	BWMLSD300012	Hex Bolt M12x40	6
13	BWMLSD300013	Nylon Lock Nut M12	9
14	BWMLSD300014	Hinge Pin	1
15	BWMLSD300015	Cotter Pin Ø4x40	3
16	BWMLSD300016	Oil Bolt	1
17	BWMLSD300017	Left Fender	1
18	BWMLSD300018	Oil Tank	1
19	BWMLSD300019	Engine	1
20	BWMLSD300020	Big Flat Washer Ø10	4
21	BWMLSD300021	Polyurethane Block	4
22	BWMLSD300022	Hex Bolt M10x30	10
23	BWMLSD300023	Rubber Washer 2	6
24	BWMLSD300024	Flat Washer Ø10	14
25	BWMLSD300025	Lock Washer Ø10	6
26	BWMLSD300026	Nylon Lock Nut M10	15
27	BWMLSD300027	Right Fender	1
28	BWMLSD300028	Wheel	2
29	BWMLSD300029	Flat Washer Ø20	2
30	BWMLSD300030	Hex Slot Thin Nut M20	2
31	BWMLSD300031	Cotter Pin Ø4x36	2
32	BWMLSD300032	Axle Cap	2
33	BWMLSD300033	Hex Bolt M8x75	4
34	BWMLSD300034	Flat Washer Ø8	8
35	BWMLSD300035	Lock Washer Ø8	12
36	BWMLSD300036	Nylon Lock Nut M8	8
37	BWMLSD300037	Oil Filter	1
38	BWMLSD300038	Rubber Washer	1
39	BWMLSD300039	Oil Filter Mounting Plate	1
40	BWMLSD300040	Clamp	2

41	BWMLSD300041	Hydraulic Hose	1
42	BWMLSD300042	Hex Bolt M6x20	6
43	BWMLSD300043	Lock Washer Ø6	6
44	BWMLSD300044	Flat Washer Ø6	6
45	BWMLSD300045	Oil Plug	1
46	BWMLSD300046	Flat Key	1
47	BWMLSD300047	Engine Bushing	1
48	BWMLSD300048	Engine Coupler	1
49	BWMLSD300049	Gear Pump Stand	1
50	BWMLSD300050	Hex Bolt M8x25	4
51	BWMLSD300051	Hex Bolt M8x30	4
52	BWMLSD300052	Gear Pump	1
53	BWMLSD300053	Connector	1
54	BWMLSD300054	O Ring Ø11x2.5	1
55	BWMLSD300055	Hydraulic Hose (Valve – Gear Pump)	1
56	BWMLSD300056	Flat Key	1
57	BWMLSD300057	Gear Pump Coupler	1
58	BWMLSD300058	Circlip for Shaft	1
59	BWMLSD300059	Coupler Cover	1
60	BWMLSD300060	Hex Bolt M5x10	4
61	BWMLSD300061	O Ring 14x2.5	3
64	BWMLSD300064	Tow Bar	1
65	BWMLSD300065	Spring	2
66	BWMLSD300066	Safety Pin	2
67	BWMLSD300067	Cotter Pin Ø3x30	2
68	BWMLSD300068	Steel Wire Snap Ring for Shaft Ø62	1
69	BWMLSD300069	Thick Flat Washer Ø12	2
70	BWMLSD300070	Hook Chain	2
71	BWMLSD300071	Hex Bolt M12x90	1
72	BWMLSD300072	Hex Bolt M12x130	2
73	BWMLSD300073	50mm Coupler	1
74	BWMLSD300074	Ball Handle	1
75	BWMLSD300075	Jockey Wheel Handle Bushing	1
76	BWMLSD300076	Jockey Wheel Handle	1
77	BWMLSD300077	Outer Sleeve	1
78	BWMLSD300078	Nylon Lock Nut M6	1
79	BWMLSD300079	Elastic Cylindrical Pin	1
80	BWMLSD300080	Hex Bolt M6x60	1
81	BWMLSD300081	Thrust Ball Bearing	1
82	BWMLSD300082	Screw Rod	1

83	BWMLSD300083	Moving Pipe	1
84	BWMLSD300084	8" Caster	1
85	BWMLSD300085	Hex Bolt M10x25	4
86	BWMLSD300086	Bonded Washer	4
87	BWMLSD300087	Bolt Connector	2
88	BWMLSD300088	Cylinder	1
89	BWMLSD300089	Hydraulic Hose (Valve – Oil Tank)	1
90	BWMLSD300090	Valve A Connector	1
91	BWMLSD300091	Front Cover Connector	1
92	BWMLSD300092	Adjustable Washer C	
93	BWMLSD300093	Wedge Pin	1
94	BWMLSD300094	Piston Rod Connector	1
95	BWMLSD300095	Hex Bolt M8x20	1
96	BWMLSD300096	Hex Nut	1
97	BWMLSD300097	O Ring Ø16x2.5	1
98	BWMLSD300098	Valve B Connector	1
99	BWMLSD300099	Nut	1
100	BWMLSD300100	Control Valve	1
101	BWMLSD300101	Screw M8x10	4
102	BWMLSD300102	Plate	1
103	BWMLSD300103	130°Joint	1
104	BWMLSD300104	Hydraulic Hose (Valve – Valve)	1
105	BWMLSD300105	Lifting Table	1

Section B. Lifting Table



Ref #	Part No.	Description	Qty
1	BWMLSDLT00001	Support Leg	1
2	BWMLSDLT00002	Lifting Table	1
3	BWMLSDLT00003	Connecting Frame	1
4	BWMLSDLT00004	Valve Mounting Plate	1
5	BWMLSDLT00005	Lift Cylinder	1
6	BWMLSDLT00006	Hinge Pin	1
7	BWMLSDLT00007	Hydraulic Hose	2
8	BWMLSDLT00008	Connector	1
9	BWMLSDLT00009	Hydraulic Hose (Valve – Oil Tank)	1
10	BWMLSDLT00010	One-Way Single Handle Control Valve	1
11	BWMLSDLT00011	Connector	1
12	BWMLSDLT00012	Angle Connector	1
13	BWMLSDLT00013	Multi-way Valve Outlet Connection	2
14	BWMLSDLT00014	Screw M5x30	2
15	BWMLSDLT00015	Nylon Lock Nut M5	2
16	BWMLSDLT00016	Washer	2

17	BWMLSFLT00017	Screw M8x25	4
18	BWMLSFLT00018	Lock Washer Ø8	6
19	BWMLSFLT00019	R Pin	2
20	BWMLSFLT00020	O Ring Ø14x2.5	1
21	BWMLSFLT00021	Bolt	1
22	BWMLSFLT00022	Safety Pin	1
23	BWMLSFLT00023	Lift Arm	1
24	BWMLSFLT00024	Safety Piece	2
25	BWMLSFLT00025	Flat Washer Ø8	2
26	BWMLSFLT00026	Hex Bolt M8x16	2
27	BWMLSFLT00027	Nylon Lock Nut M16	1
28	BWMLSFLT00028	Hex Bolt M16x70	1
29	BWMLSFLT00029	Connector Z1/2-M14X1.5	1

Customer Service:

303 Warrigal Road, Cheltenham, Victoria 3192, Australia

Telephone: 13000 454 585

Website: www.BWMachinery.com.au

Email: admin@bwmachinery.com.au

Spare parts are available from our dealers and our official website